

Controlling the Remote

TV, Set-Top-Box

Use one remote to control multiple devices.

Menu

Displays the menu.

Arrow Keys and OK/Sel

Navigate and select onscreen choices.

Guide

Opens the Interactive Program Guide.

Red, Green, Yellow, Blue

Access additional features on set-top box.

Volume Up and Down

Raise or lower the volume.

On Demand

Access video on demand services.

Mute

Turn the sound off or on.

Aspect Ratio*

Temporarily change the conversion mode from Original Size to Fit Screen.



Off

Turn on/off a selected device.

Info

Display current channel and Program information. Press again for more detail.

Exit

Exit the current screen.

Page +/-

Page up or down in lists and Interactive Program Guide.

Channel Up and Down

Changes to the next higher or lower channel.

Last

Recall the last channel you were watching.

Fav

View your favorite channels.

Number Keys (0-9)

Directly select a channel or enter options.

Input

In TV control mode, will change the input of the device you are controlling.



WHAT'S ON TV?

There's more than one way to see what's showing on TV.

Info Button

Press Info and you will see the name and a description of the current program at the top of the screen.

OK Button

Press OK to show the 'Now Playing' bar and you will see what program is currently playing.

Guide Button

This is the most comprehensive view of what's on. Go ahead and page through... you're bound to find something to watch.

Browse Button

Press Browse (right arrow) to show the channel you are currently tuned to at the top of the screen. At the bottom of the screen, the 'Info Bar' shows you the channel number, channel name, current date and time, program name, date and time the program airs, a progress bar, and the program that airs next.

Remote Set Up

Pair the TV to the Remote

1. Turn on the TV.
2. Point the remote at the TV and press and hold the TV key for 3 seconds until the TV LED blinks off and turns back on. Continue holding the TV key and press the number keys, one at a time, starting with 1, then 2, 3... 0. Stop pressing the number keys when the device turns off.
3. Release the TV key to save the code. The TV LED will blink twice to confirm the code is stored.

Programming the All Off Button

1. Press the STB button.
2. Press the ALL OFF button and the OK/SEL button simultaneously for 3 seconds. The STB button will turn on for 30 seconds.
3. Press the TV button and then the POWER button.
4. Press the 5 number key to save the ALL OFF commands. The STB button will blink twice to confirm the TV has been saved.



1006 12th Street • Aurora, NE 68818 • 402.694.5101

CobaltTV.com

Remote Control Guide

