





Remote Control Set Up



Make sure TV is ON before starting the remote control setup.

1 Press and hold **SETUP** until it blinks twice. 

2 Press the **TV POWER** key. 

3 Press and hold down the **OK/SELECT** key. 

4 When the TV turns off, let go of the **OK/SELECT** key. 

LOW BATTERY  The **CABLE POWER** button will blink 5 times with each key-press when the batteries need replacement. 




1008 N. Main Street • Henderson, NE 68371 • 402.723.4848

CobaltTV.com

Remote Control Guide



Controlling the Remote



WHAT'S ON TV?

There's more than one way to see what's showing on TV.



Info Button

Press **INFO** and you will see the name and a description of the current program at the top of the screen.



OK Button

Press **OK** to show the **Now Playing** bar and you will see what program is currently playing.



Guide Button

This is the most comprehensive view of what's on. Go ahead and page through . . . you're bound to find something you want to watch.



Right Arrow Browse Button

Press the **Right Arrow** to view the channel you are currently watching. At the bottom of the screen, the **Info Bar** shows you the channel number, channel name, time the program airs, a progress bar, and the program that airs next.

*Available with DVR